



CLEANING

OILED FLOORS

REGULAR CLEAN

Tools

- 2 x Buckets (5 litres each)
- 1 x Mop (we recommend Sabco Twister Cotton Mop)
- 1 x WOCA Natural Soap

Method

1. Sweep or vacuum floor thoroughly, prior to mopping.
2. Shake bottle of Natural Soap well. Pour ½ cup of Natural Soap in 1st bucket, along with 5 litres of warm water. This will be your soap solution.
3. Fill 2nd bucket with cold water. This will be your rinsing bucket.
4. Dunk the mop in the soap solution, and gently wring out.
5. Mop in small areas along the length of the floorboards. Leave the soap solution on for a minute or two depending on how dirty the floor is.
6. Rinse the mop thoroughly in your rinsing bucket and wring out hard.
7. Dunk the mop back in the soap solution, wring out hard ensuring the mop is as dry as possible. Re-mop the area you have just cleaned, trying to absorb as much moisture as possible.
8. Rinse the mop again in the rinsing bucket. Wring out hard.
9. Repeat steps 4-8 until the soap solution has been applied to the entire floor.

Notes

1. Repeat above cleaning instructions if the floor is extremely dirty.
2. Clean tools with water and soap.
3. Ensure floor is completely dry before applying any other products. A minimum of 8 hours drying time is recommended.

BUILDER'S CLEAN

Tools

2 x Buckets (5 litres each)
1 x Mop (we recommend
Sabco Twister Cotton Mop)
1 x WOCA Intensive Wood
Cleaner

Method

1. Sweep or vacuum floor thoroughly, prior to mopping.
2. Shake bottle of Intensive Wood Cleaner well. Pour ½ cup of Intensive Wood Cleaner in 1st bucket, along with 5 litres of warm water. This will be your soap solution.
3. Fill 2nd bucket with cold water. This will be your rinsing bucket.
4. Dunk the mop in the soap solution, and gently wring out.
5. Mop in small areas along the length of the floorboards. Leave the soap solution on for a minute or two depending on how dirty the floor is.
6. Rinse the mop thoroughly in your rinsing bucket and wring out hard.
7. Dunk the mop back in the soap solution, wring out hard and then re-mop the area you have just cleaned with the soap solution.
8. Rinse the mop again in the rinsing bucket. Wring out hard.
9. Repeat steps 4-8 until the soap solution has been applied to the entire floor.

OCCASIONAL CARE & MAINTENANCE

Tools

- 2 x Buckets (5 litres each)
- 1 x Mop (we recommend Sabco Twister Cotton Mop)
- 1 x WOCA Oil Refreshing Soap

Method

1. Sweep or vacuum floor thoroughly, prior to mopping.
2. Shake bottle of Oil Refreshing Soap well. Pour 1 cup of Oil Refreshing Soap into 1st bucket, along with 5 litres of warm water. This will be your oil solution.
3. Fill 2nd bucket with cold water. This will be your rinsing bucket.
4. Dunk the mop in the oil solution, and gently wring out.
5. Mop in small areas along the length of the floorboards.
6. Rinse the mop thoroughly in your rinsing bucket and wring out hard.
7. Dunk the mop back in the oil solution, wring out hard ensuring the mop is as dry as possible. Re-mop the area you have just cleaned, trying to absorb as much moisture as possible.
8. Rinse the mop again in the rinsing bucket. Wring out hard.
9. Repeat steps 4-8 until the oil solution has been applied to the entire floor.
10. Leave the floor to dry for approximately 2 hours.

SPOT CLEAN

Tools

- 1 x Brush
- 1 x Cotton Cloth
- 1 x WOCA Spot Remover
- 1 x Royal Oak Repair Oil
- Water

Method

1. Before using Spot Remover, we advise patch-testing a small area of floorboards, in a non-visible spot, to ensure there is no undesired reaction.
2. Spray Spot Remover evenly on the stain.
3. Leave Spot Remover to dissolve the stain for 10-20 minutes.
4. Scrub with a brush until the stain has been dissolved.
5. Wipe with a cloth that has been wrung out in warm water.
6. Repeat application if necessary.
7. Once dried, apply multiple coats of Royal Oak Repair Oil to cleaned area.

TANNIN SPOT CLEAN

Tools

- 1 x Brush
- 1 x Cotton Cloth
- 1 x WOCA Tannin Spot Remover
- 1 x Royal Oak Repair Oil
- Water

Method

1. Before using Tannin Spot Remover, we advise patch-testing a small area of floorboards, in a non-visible spot, to ensure there is no undesired reaction.
2. Spray Tannin Spot Remover evenly on the stain.
3. Leave Spot Remover to dissolve the stain for 30-60 minutes.
4. Wipe with a cloth that has been wrung out in warm water.
5. Repeat application if necessary.
6. Once dried, apply multiple coats of Royal Oak Repair Oil to cleaned area.

Important

Clean all tools used in the process with water and soap after each use. In food preparation areas, ensure that spilled fats and oils are cleaned immediately with Intensive Cleaner Spray or warm soap water.

Royal Oak Floors do not warranty the surface coating, it is the responsibility of the Buyer to ensure due care and maintenance is conducted to ensure longevity of the floor.

WOCA Natural Cleaning Solutions

We recommend WOCA cleaning products for all our flooring products. WOCA is available from our online shop or direct from our showroom. Postage is available Australia wide. For further information please refer to the care instructions on our website.